

TO ADJUST ADDUCTION/ABDUCTION:

- Step 1:** Begin by pressing the STOP button.
- Step 2:** Press the blue ADD/ABD button and the red STOP button simultaneously to initiate a program change.
- Step 3:** Press the blue ADD/ABD button once more to move arrow (>) to point towards the numbers on the RIGHT SIDE of the remote.
- Step 4:** Use the upward arrows to increase (+) range of motion (ROM) or use the downward arrows to decrease (-) ROM.
- Step 5:** Press the green START button twice to start the CPM
- Step 6:** If CPM stops, press the green START button again.

TO ADD ROTATION:

- Step 1:** Begin by pressing the STOP button.
- Step 2:** Press the blue ROTATION button 2 x to move arrow (>) to point towards the numbers on the RIGHT SIDE of the remote.
- Step 3:** Repeat steps 3, 4 and 5 as above.

